



Operator Interface

MICRO/I HG2G, HG1F/2F/2S/3F/4F
WindO/I®-NV2

Main Menu

Instruction Manual

Describes the procedures for creating projects, the communication format between MICRO/I and the PC, and the operations graphics and parts on the MICRO/I.

Communication Manual

Describes the connection procedures for PLCs to MICRO/I, and the communications including the O/I-Link communication.

Hardware Manual

Describes the hardware specifications of the HG2G, HG1F, HG2F, HG3F/4F, HG2S and the optional parts including the communication cables.